
west elm


Harmony Collection assembly instructions




- 1. Choose the proper leg that matches the collection piece using the chart on back side.
- 2. Remove temporary shipping leg and layout wrapped legs from packaging.
- 3. Attach each leg by aligning it on the pre-drilled holes underneath the frame. Insert bolt with washer into the frame. Hand tighten bolts. <u>Warning! Do not tighten until all bolts are secured.</u>
- 4. Once all bolts are in, tighten completely using the hex key provided.

Additional information: Shelf Legs can be turned inwards to hide shelf or turned outwards to be used as a support for a sectional piece. See image below.

Warning! Armless Pieces need to be locked together using brackets and properly resting on shared leg.



A. Visible shelf leg and sectional brackets for connecting



B. Invisible shelf leg for stand-alone unit

west elm

Harmony Collection assembly instructions

Chart 1. Harmony Leg Placement

