

west elm

Harmony Sofa assembly instructions






- ! Do not throw away packaging materials until assembly is complete.
- ! Assemble this item on a soft surface, such as cardboard or carpet, to protect finish.
- ! Proper assembly of this item requires 2 people.





1. Choose the legs that match your sofa frame.



2. Attached each leg by aligning it on the pre-drilled holes underneath the sofa frame. Insert bolts (A) into the leg beam as shown and tighten using the allen key (B).

