



# west elm: futon lounger frame (full size)

assembly instructions




# west elm: futon lounger frame (full size)


## assembly instructions




back deck frame




lounger deck frame




seat deck slat (5x)



back deck leg




seat deck slat support (2x)

! Tools required: 

! Do not throw away packaging materials until assembly is complete.





! Assemble this item on a soft surface, such as cardboard or carpet, to protect the finish.



seat deck leg





seat deck center strut

<p>A</p>  <p>bolt: 7/16"DIA x 3 1/2" 2x</p>	
<p>B</p>  <p>bolt: 7/16"DIA x 2 3/8" 4x</p>	<p>C</p>  <p>screw 30x</p>
<p>D</p>  <p>nut 6x</p>	<p>E</p>  <p>metal washer 6x</p>
<p>F</p>  <p>allen key 1x</p>	<p>G</p>  <p>wrench 1x</p>

# west elm: futon lounger frame (full size)

assembly instructions



1. Attach slats to seat deck and center strut using wood screws (C). Screw into pre-drilled holes provided on slat supports and center strut.



# west elm: futon lounge frame (full size)

## assembly instructions

2. Connect back deck frame, seat deck frame, lounge frame and seat deck leg together.
3. Complete assembly by adding back deck leg.




**CARE INSTRUCTIONS.** Hardware may loosen over time. Periodically check that all connections are tight.

Wipe with a soft, dry cloth. To protect the finish, avoid the use of all chemicals and household cleaners.



# west elm: futon lounger frame (full size)

operating instructions



---

LOUNGE TO BED POSITION:



---

BED TO LOUNGE POSITION:

