






# west elm: medina tray stand


assembly instructions




<p><b>A</b></p>  <p>bolt</p> <p>4x</p>	<p><b>B</b></p>  <p>lock washer</p> <p>4x</p>
<p><b>C</b></p>  <p>metal washer</p> <p>4x</p>	<p><b>D</b></p>  <p>allen key</p> <p>1x</p>
<p><b>E</b></p>  <p>plate</p> <p>1x</p>	<p><b>F</b></p>  <p>eva pad</p> <p>4x</p>

# west elm: medina tray stand

assembly instructions





eva 4x ○



# west elm: medina tray stand

assembly instructions



Adjustable levelers are installed in the legs to accommodate uneven flooring. To adjust these levelers, simply turn them counterclockwise to raise the leg.

**CARE INSTRUCTION**

Hardware may loosen over time. Periodically check that all connections are tight  
Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.