Ultimate Art Easel
Chevalet d'art ultime

3 years +
3 ans et plus



⚠ WARNING:

This toy requires adult assembly.
Loose parts pose potential sharp points and choking hazards for children under 3yrs.
Pls keep away from children's reach until fully assembled.
Do not use power tools or over tighten which may result in wood splitting or cracking.
Do not fully-tighten the bolts until all parts are attached.

⚠ MISE EN GARDE

Ce jouet nécessite d'etre assemblé par un adulte.
Les pièces non assemblées peuvent posséder des coins pointus et représenter des risques d'étouffement pour les enfants de moins de 3 ans.
Veuillez les garder hors de la portée des enfants jusqu'à ce que l'assemblage soit terminé.
N'utilisez pas d'outil électrique ou évitez de trop serrer, car ceci pourrait faire fendre ou craquer le bois.
Ne pas serrer les boulons à fond tant que tous les boulons ne sont pas en place.

Contents
Contenu

NOTE: Please read instructions before starting to assemble
NOTE: Veuillez lire les instructions avant de commencer l'assemblage