west elm

Mid-Century Overarching Wall Sconce

Assembly Instructions

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- For your safety and convenience, it is strongly recommended that two people install the lighting fixture.
- This fixture has been rated for up to one (1) **100-watt maximum TYPE A standard incandescent light bulb** (not included) or one (1) **23-watt compact fluorescent light bulb** (not included) or one (1) **9-watt SBLED light bulb** (included). To avoid the risk of fire, do not exceed the recommended wattage.
- Use with approved West Elm Shades only, having a minimum opening diameter of 4 inches and a minimum lamp-toshade spacing of 3-1/2 inches.
- This lamp is meant for indoor use. DRY LOCATIONS ONLY.
- Save these instructions.


WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Pre-assembly:


- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended.

Tools Required (not included):



Mid-Century Overarching Wall Sconce

Assembly Instructions




To assemble:

- 1. This mounting hardware is meant for dry wall/stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance. For safety and ease of mounting, installation is recommended using two people.
- 2. Stud mounting is always best, so try to position the Mounting Plate (D) over the studs . Use a stud finder to locate a stud in desired wall location. If Mounting Plate (D) aligns with stud, only use provided Wall Screws (B). If there is no stud, the Wall Anchors (A) and Wall Screws (B) are both required.
- 3. For Drywall Mounting: Assemble and install the Wall Anchors (A) and Wall Screws (B) using the steps as outlined in Section "FOR DRYWALL MOUNTING" below.
- 4. For Mounting to Joist: Assemble and install the Wall Screws (B) using the steps as outlined in Section "FOR MOUNTING TO JOIST" below.
- 5. After properly assemble the Wall Anchors (A) and Wall Screws (B) onto the wall, install the lighting fixture onto the wall using the steps as outlined in Section" Install the Light Fixture onto the Wall"

Mid-Century Overarching Wall Sconce Assembly Instructions

For drywall mounting:



Separate the Mounting Plate (D) from the Canopy (E) by removing the 4 Canopy Screws (C). Do not discard the Canopy Screws (C) as these will be used later.


- 1. Place the Mounting Plate(D) against the wall at the desired hanging location.
- 2. Mark the mounting location of the 2 holes of Mounting Plate (D) onto the wall using a pencil.Use a carpenter's level to ensure a level installation.
- 3. MAKE SURE THAT A POWER OUTLET IS REACHABLE BY THE CORD without straining the cord.

Use a Phillips Screwdriver to insert the Wall Anchors (A) at the marked keyhole locations. Do not "push" or drive the Wall Anchors (A) into the wall, it is Designed to bore into the wall like a drill bit. Slowly turn the Wall Anchors (A) in a clockwise while applying pressure until the flange just touches the wall.

- 1. Attach the Mounting Plate (D) onto the wall aligning the 4 slots on Mounting Plate (D) with the 4 installed Wall Anchors(A).
- 2. Insert the Wall Screws (B) and tighten each to secure Mounting Plate (D) firmly onto the wall.

Mid-Century Overarching Wall Sconce Assembly Instructions

For mounting to joist:



Separate the Mounting Plate (D) from the Canopy (E) by removing the 4 Canopy Screws (C). Do not discard the Canopy Screws (C) as these will be used later.

- 1. Place the Mounting Plate(D) against the wall at the desired hanging location.
- 2. Mark the mounting location of the 4 holes of Mounting Plate (D) onto the wall using a pencil
- Use a carpenter's level to ensure a level installation. MAKE SURE THAT A POWER OUTLET IS REACHABLE BY THE CORD without straining the cord.


Pre-drill pilot holes at the marker locations. This will make installing the Wall Screws (B) onto the wall easier.

- 1. Attach the Mounting Plate (D) onto the wall aligning the 4 slots on Mounting Plate (D) with the 4 marked locations.
- Insert the Mounting Screws (B) and tighten each to secure the Mounting Plate (D) firmly onto the wall by using a screwdriver.

Mid-Century Overarching Wall Sconce


Assembly Instructions

Install the Light Fixture onto the Wall:




Assembly Instructions

To Adjust Length of the Lamp Arm :



If needed, loosen the Knob (G) and move the Extension Arm (H) to front or back by hand until it is determined, then tighten the Knob (G) in a clockwise direction until the Extension Arm (H) is secured.

To Adjust Length of the Lamp Arm & Shade :



- 1. If needed, The Lamp Arm (F) can be moved to the left or right by hand until it is determined.
- 2. If needed, adjust the Lamp Shade (J) to the desired angle by gently moving the Lamp Shade (J) by hand until it is determined.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

Thank you for your purchase Stores | catalog | <u>www.westelm.com</u> USA 888-922-4119