


## installation guide ACTIV-1


sit-to-stand desks

















- Assemble center, left and right stretcher bar
- Preset stretcher bar to desired length and tighten with six M5 screws.



Mount motor unit on stretcher bar using three M5 screws.












1 Attach both feet using M5 screws.














Orient yourself to the table assembly by facing as a user to identify left and right motor.


After the hand set and control box are connected properly, connect power plug.





- To Program Up to 3 Presets: Use the up/ down arrows to find desired height, then press "M" followed by the number 1, 2, or 3.
- To Test Programmed Height: Use the up/ down arrows to adjust the table to a height other than the preset height. Then push and hold the number you programmed to see if it automatically adjusts to the height programmed in Step 1.

Note: If it does not adjust to the programmed height, repeat Step 1 followed by Step 2.





Caution: Once the preset number is pushed, the base will automatically moved to the programmed height.



5 Day Open Plan we provide exceptional experiences with reliable, easy interactions and successfully fulfilled orders in only 5 days



915 Walsh Avenue / Santa Clara, CA 95050 (877) 801-0370 amqsolutions.com